

LD400 PARTS LIST					
NO.	DESCRIPTION		NO.	DESCRIPTION	
	Hex Bolt		38.2	Reducer End Cap	
2	Waasher		38.3	Motor	
3	Top Cap		39F	Control Board Assy	
4	Dust Cap		39.1	Control Board	
5	Hex Bolt		39.2	Light Guide	
6	Air Cap		39.3	Button	
7	Valye Assy		39.4F	PCB	
8	0-Ring		39.5	ScreW	
9	0-Ring		39N	Control Bogrd Assy	
10	Gasket		39.1	Control Board	
11	DriverBlade Unit		39.2	Light Guide	
11.1	Sngp Ring		39.3	Button	
11.2	Sealing Ring		39.4N	PCB	
11.3	0-Ring		39.5	Screw	
11.4	Driver Blade Unit		40	Spring	
	Driver Blade		41	Trigger	
	Psiton		42	Dust Ring	
12	Cylinder		43	Spring	
13	0-Ring		44	Sleeve	
14	Bumper		45	Pawl	
16	Rubber Pad		46	Washer	
17	Screw		47	HexBolt	
18F	Housing(R		48	Hex Bolt	
18N	Housing(R)		49	Adjusting Piece Assy.	
19	Locating Ring		49.1	Pin	
20	Snap Joint		49.2	Positioning Seat	
21	Rubber Retainer		49.3	Pin	
22	Upper Filter Net		49.4	Hex Bolt	
23	Lower Filter Net		49.5	Spring	
24	Retainer		49.6	Bolt	
25	Seal		49.7	Adjusting Nut	
26	Ball Begring		49.8	Spring	
27	0-Ring		49.9	Steel Ball	
28	Pin		49.10	Adjusting Piece	
29	Gear		49.11	Cover	
30	Transmission Wheel Assy		49.12	Retainer	
30.1	Spring Stop		49.13	Magnet	
30.2	Spring		50	Driver Guide Cover	
30.3	Pin		50.1	Driver Guide Cover	
30.4	Spring Stop		50.2	Auxiliary Handle	
30.5	Spring		50.3	Auxiliary Handle Fixing Seat	
30.6	Bearing		50.4	Hex Bolt	
30.7	Magnet		51	Magazine Assy.	
31	Parallel Key		51.1	DriverGuide	
32	Hex Bolt		51.2	Hex Bolt Unit	
33	Cylinder		51.3	Hex Bolt Unit	
34	Hall Sensor Module		51.4	Nail Blocking Board	
	Hall Element		51.5	Baffle(R)	
	Spacer		51.6	Pin	
35	Micro Switch Assy		51.7	Nail Strip	
	Micro Switch		51.8	Coil Spring hook	
	Wire w/Terminal		51.9	Coil Spring Core	
36	Reducer Assy.		51.10	Coil Spring	
36.1	Reducer Housing		51.11	Pusher	
36.2	Output Shaft		51.12	Coil Spring Pin	
36.3	Gear		51.13	Spring	
36.4	Ring Gearl		51.14	Bushing	
36.5	Carrier I		51.15	Spring Pin	
36.6	Pin		51.16	Pin	
36.7	Gear		51.17	Baffle(L)	
36.8	Carrier II		51.18	Magazine	
36.9	Ring Gear II		51.19	Tail Hanger	
36.10	Gasket		52F	Housing(L)	
37	Pin		52N	Housing(L)	
38	Motor Assy.		53	Hook	
38.1	Screw				

Parts marked in **red** are in stock

FREEMAN

ASSEMBLY DRAWING

MODEL: LD400

