

## LD34100 PARTS LIST

| NO.         | DESCRIPTION               | NO.   | DESCRIPTION           |
|-------------|---------------------------|-------|-----------------------|
|             | Hex Bolt                  | 38    | Motor Assy.           |
| 2           | Washer                    | 38.1  | Screw                 |
| 3           | Top Cap                   | 38.2  | Reducer End Cap       |
| 4           | Dust Cap                  | 38.3  | Motor                 |
| 5           | Hex Bolt                  | 39F   | Control Board Assy.   |
| 6           | AirCap                    | 39.1  | Control Board         |
| 7           | Valve Assy.               | 39.2  | Light Guide           |
| <b>8</b>    | <b>O-Ring</b>             | 39.3  | Button                |
| <b>9</b>    | <b>O-Ring</b>             | 39.4F | PCB                   |
| 10          | Gasket                    | 39.5  | Screw                 |
| <b>11</b>   | <b>Dirver Blade Unit</b>  | 39N   | Control Board Assy.   |
| 11.1        | Snap Ring                 | 39.1  | Control Board         |
| 11.2        | Segling Ring              | 39.2  | Light Guide           |
| 11.3        | Driver Blade Unit         | 39.3  | Button                |
|             | Driver Blade              | 39.4N | PCB                   |
|             | Piston                    | 39.5  | Screw                 |
|             | Pin                       | 40    | Spring                |
| 12          | Cylinder                  | 41    | Trigger               |
| <b>13</b>   | <b>O-Ring</b>             | 42    | Dust Ring             |
| <b>14</b>   | <b>Bumper</b>             | 43    | Spring                |
| 15          | Seal                      | 44    | Sleeve                |
| 16          | Rubber Pad                | 45    | Pawl                  |
| 17          | Screw                     | 46    | Washer                |
| 18F         | Housing                   | 47    | Hex Bolt              |
| 18N         | Housing(R)                | 48    | Hex Bolt              |
| 19          | Locating Ring             | 49    | Adjusting Piece Assy. |
| 20          | Snap Joint                | 49.1  | Pin                   |
| 21F         | Rubber Retainer           | 49.2  | Hex Bolt              |
| 22          | Upper Filter Net          | 49.3  | Pin                   |
| 23          | Lower Filter Net          | 49.4  | Positioning Seat      |
| 24          | Retainer                  | 49.5  | Spring                |
| 25          | Seal                      | 49.6  | Bolt                  |
| 26          | Ball Bearing              | 49.7  | Adjusting Nut         |
| <b>27</b>   | <b>O-ring</b>             | 49.8  | Spring                |
| 28          | Pin                       | 49.9  | Steel Ball            |
| 29          | Gear                      | 49.10 | Adjusting Piece       |
| 30          | Transmission Wheel Assy   | 49.11 | Cover                 |
| 30.1        | Spring Stop               | 49.12 | Retainer              |
| 30.2        | Spring                    | 49.13 | Magnet                |
| 30.3        | Pin                       | 50    | Driver Guide Cover    |
| <b>30.4</b> | <b>Spring Stop</b>        | 51    | Magazine Assy.        |
| <b>30.5</b> | <b>Spring</b>             | 51.1  | Driver Guide          |
| 30.6        | Bearing                   | 51.2  | Hex Bolt Unit         |
| 30.7        | Magnet                    | 51.3  | Hex Bolt Unit         |
| 31          | Parallel Key              | 51.4  | Mandrel               |
| 32          | Hex Bolt                  | 51.5  | Wheel                 |
| 33          | Cylinder                  | 51.6  | Coil Spring           |
| <b>34</b>   | <b>Hall Sensor Module</b> | 51.7  | Coil Spring hook      |
|             | Hall Element              | 51.8  | Pin                   |
|             | Spacer                    | 51.9  | Pusher seat           |
| <b>35</b>   | <b>Micro Switch Assy</b>  | 51.10 | Pusher                |
|             | Micro Switch              | 51.11 | Magazine              |
|             | Wire w/Terminal           | 51.12 | Hex Bolt Unit         |
| 36          | Reducer Assy.             | 51.13 | Tail Hanger           |
| 36.1        | Reducer Housing           | 51.14 | Screw                 |
| 36.2        | Output Shaf               | 51.15 | Fixed Block           |
| 36.3        | Gear                      | 51.16 | Nail Strip            |
| 36.4        | Ring Gear I               | 51.17 | Shell                 |
| 36.5        | Carrier I                 | 51.18 | Hex Bolt              |
| 36.6        | Pin                       | 51.17 | Shell                 |
| 36.7        | Gear                      | 51.18 | Hex Bolt              |
| 36.8        | CarrierII                 | 52F   | Housing(L)            |
| 36.9        | Ring Gear II              | 52N   | Housing(L)            |
| 36.10       | Gasket                    | 53    | Hook                  |
| 37          | Pin                       | 54    | Hex Bolt)             |

Parts marked in **red** are in stock

