

LDT64 PARTS LIST			
NO.	DESCRIPTION		NO. DESCRIPTION
1	End Cover		43 Hex Bolt
2	Hex Bolt		44 Screw Set A
3	End Cap		45 Lock Nut
4	Spring		46 Cam
5	Limit Bushing		47 Gear
6	cushion		48 Bearing
7	Guide Rod		49 Pin
8	Spring		50 Begring
9	Piston ASsy		51 Reducer Assy
	Piston		51.1 Reducer Housing
	Pin		51.2 Begring
	Driver Blade		51.3 Output Shaft
10	Bumper		51.4 Parallel Key
11	Cylinder		51.5 pin
12	Screw Set D		51.6 Gear
13	Mounting Plate		51.7 Ring Gear I
14	Pin		51.8 Screw
15	Spring		51.9 Carrier I
16	Bracket		51.10 Gear
17	Bushing		51.11 Ring Gear II
18	Spring		51.12 Gasket
19	Steel ball		51.13 pin
20	Washer		51.14 Carrier II
21	Bracket		52 Pin
22	Retainer		53 Motor Assy
23	Guide Rod		53.1 Reducer End Cap
24	Spring		53.2 Motor Gegr Assy
25	WCE-1		53.3 Shell
26	No-Mar Tip		54 Front Cap
27	Safety switch wiring harness		55 Screw Set A
28	Screw		56 Screw Set A
29	Screw		57 Cover Plate
30	Lock Nut		58 pin
31	Adjusting Nut		59 Nose Casing
32	Hex Bolt		60 I gtchAssy
33	Screw		61 Nose Cover
34F	Housing		62 pin
34N	Housing(R)		63 Magazine Assy.
35	LED Ligh		63.1 Hex Bolt
36	Position switch wiring harness		63.2 Hex Bolt
37	Trigger		63.3 Nose
38	Spring		63.4 Spring
39	Micro Switch		63.5 Pusher
40F	PCBA		63.6 Guide
40	HMI		63.7 Pin
40.2	Button		63.8 Magazine
40.3	Light Guide		63.9 Hex Bolt
40.4F	circuit board		63.10 spring washer
40.5	Screw		63.11 Limit Plate
40N	PCBA		63.12 Hex Bolt
40.1	HMI		63.13 Support Plate
40.2	Button		63.14 Shell
40.3	Light Guide		63.15 Pin
40.4N	circuit board		63.16 Flat Spring
40.5	Screw		63.17 Wheel
41F	Housing(L)		63.18 Strip
41N	Housing(L)		64 Hex Bolt
42	Belt Hook		65 Bracket

Parts marked in **red** are in stock

FREEMAN

ASSEMBLY DRAWING

MODEL: LDT64

